
7. Water & Air diagrams

Figure 36 Water &Air diagram（delivery head）



1. 1/8" orange,the total switch back air path
2. 1/8" black, the total switch supply air path
3. 1/8" blue, water tube
4. 1/8" yellow, main air supply tube
5. 1/4" black, pedal drive air
6. 1/8" red, state valve
7. 1/8" white, reserved
8. 1/8" brown, reserved

Figure 37 Classic100 Water &Air diagram（water unit）






Figure 38 Classic101 Water &Air diagram（water unit）





1. 1/8" orange,the total switch back air path
2. 1/8" black, the total switch supply air path
3. 1/8" blue, water tube
4. 1/8" yellow, main air supply tube
5. 1/4" black, pedal drive air
6. 1/8" red, state valve
7. 1/8" white, reserved
8. 1/8" brown, reserved
12. 1/4"red, for cuspidor
13. 1/4"orange, for cuspidor
14. 1/4"Green, for cuspidor
15. Drainage pipe, connect to cuspidor